52.3 REMOVE, SUPPLY AND INSTALL SNOW FENCE

52.3.1 GENERAL

The Work consists of supplying and installing, maintaining and removing temporary snow fence on an annual basis.

Other types of snow fence, including permanent large fence and wooden lathe and plastic fence that are installed and left up, are not included in this specification. Any work required on these other types of fences will be specified in the Special Provisions or negotiated as Extra Work in accordance with Specification 1.2 General (For Maintenance Work).

52.3.2 MATERIALS

The Contractor shall supply all required snow fence material from the Alberta Transportation Approved Products list. Fence material shall be a minimum of 1.22 metres in height and shall have a uniform porosity of 50% - 60%.

Salvaged snow fence material may be re-used provided it is in a condition suitable to the Engineer.

52.3.3 PROCEDURE

Snow fence shall be installed and maintained such that the maximum ground clearance is 300 mm and the minimum ground clearance is 150 mm. The snow fence material shall remain straight and plumb for the length of time that it is installed.

The Contractor shall maintain the newly installed snow fence for the duration of the warranty period. The work area shall be restored to its original condition immediately upon completion of any installation, maintenance or removal operation. Restoration includes, but shall not be limited to the removal of staples and wire ties, which may have fallen on the ground, and the filling of post holes.

52.3.4 TIME TO COMPLETE

The Contractor shall complete the Work within 30 calendar days of the issuance of the Work Order.

52.3.5 MEASUREMENT AND PAYMENT

Measurement will be made in metres of the length of snow fence installed or removed.

Payment for supplying and installing snow fence will be made at the applicable unit price bid per metre for "Snow Fence - Supply and Install". This payment will be full compensation for supplying and installing the

snow fence material and all labour, materials, equipment, tools and incidentals necessary to complete the Work.

Payment for removing snow fence will be made at the unit price bid per metre for "Snow Fence - Remove". This payment will be full compensation for removal and disposal or salvage of the snow fence materials and all labour, equipment, tools and incidentals necessary to complete the Work.

Maintaining the installed snow fence and restoring the work area to its original condition will be considered incidental to the Work and will not be paid for separately.

52.3.6 WARRANTY

The warranty period for the supply and installation of snow fence will extend to May 1, in the year following the installation or until a Work Order is issued for removal of the snow fence, whichever occurs first.

There is no warranty required for removal of snow fence.